


# owner's manual





Intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.




Intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

CAUTION: Risk of electrical shock — DO NOT OPEN

CAUTION: To reduce the risk of electric shock, do not remove cover. No user serviceable parts inside. Refer Servicing to qualified service personnel.

Congratulations and thank you for purchasing the RMC™ 2010 foot controller.

The RMC 2010 is a user-friendly foot controller that will allow all 128 MIDI pre-sets to be transmitted to any unit that receives MIDI program change commands, from the Peavey Pro-Fex™ to the DPM® 3<sup>SE</sup> or any other MIDI compatible unit. The RMC 2010 features **two large LEDs** for the "bank" number and MIDI preset number, **increment and decrement switches** to change the "bank" number, **ten numbered switches** for accessing the numbered presets within each "bank," and a **four position DIP switch** for controlling the MIDI channel and the LED display mode (2 modes). The foot controller will transmit on channels 1 through 8.



## Top Descriptions

### 1. "Bank" and Preset LEDs.


The "bank" LED will display the numbers 0 through 9 and the letters A, b, and C.  
The preset LED will display the numbers 0 through 9.

### 2. (+) increment and (-) decrement switches.

These switches are used to access the different banks.

### 3. Direct access preset control switches.

These switches are used to access the presets and transmit the MIDI program change command to the receiving unit.



## Back Descriptions

### 1. Power supply plug.

Use only the 9 volt DC 200mA adaptor provided. (Peavey part #70900666.)

### 2. MIDI Out jack.

This is used to connect to the receiving unit.


### 3. DIP Switch.

This is used to control the MIDI transmit channel and LED display settings.

### The DIP Switch:

#### *MIDI Channel Control*

The switches labeled 2, 3, and 4 control which MIDI channel the program change command will be sent on, to the receiving unit. The following figure provides the switch positions for each MIDI channel possible (channels 1 through 8 are possible).



**Note:** To change the MIDI channel number *after* power has been turned on, change the DIP switch setting. The new MIDI channel number will flash in the LEDs to verify a change has been made.

## *Display Mode Control*

The switch labeled **1** controls the display mode of the LEDs located in the upper left corner of the RMC 2010. The RMC 2010 will display preset numbers as 0 through 9 or 1 through 10. This feature allows you to match the RMC 2010 display with the display on the receiving unit. Some receiving units display program presets as 0 through the maximum number of programs, such as the UltraVerb™ II, while other units display the program presets as 1 through the maximum number of programs, such as the Pro-Fex. The RMC 2010 display allows you to see a number for number correspondence between the RMC 2010 and any MIDI compatible unit you may be using. The following figure shows the switch setting for each display option.



Default Display Mode  
0 thru 9 displayed in  
preset LED



Optional Display Mode  
1 thru 10 displayed in  
preset LED and Bank LED

**Note:** To change the display mode unplug the power supply; change the DIP switch setting, then plug the power supply in, restoring power to the RMC 2010.

### *Default Display Mode*

In this mode, the preset number displayed in the right LED will correspond to the receiving unit's display, if the receiving unit displays 0 through the maximum number of programs. This mode also corresponds to the numbers screened on the top of the unit.

### *Optional Display Mode*

In this mode, the preset number displayed in the right LED will correspond to the receiving unit's display, if the receiving unit displays 1 through the maximum number of programs, this mode will display a number one greater than the numbers screened on the top of the unit.

**Note:** In the default display mode it is necessary to change banks by pressing the (+) or (-) switches. In the optional display mode, banks may be changed in a continuous fashion; Each time the switch screened as 9 is pressed, the bank will increment by 1.

*Example:* Suppose you are in the *default* display mode and the display shows:



If you want to go to the next preset, first you have to press the (+) increment switch. The display now shows:



Next, press the switch labeled 0. The display shows:



In this example, the preset number transmitted is 10.

Now, suppose you are in the *optional* display mode. The display shows:



(Remember, the number displayed in this mode is one greater than the number on the switch pressed.)

If you want to go to the next preset, simply press the switch labeled 9 and the display will show:



You are now in the next bank and able to continue pressing presets without ever touching the (+) increment or (-) decrement switches. In this example, the preset number transmitted is 9.

**Note:** The default factory setting for each switch should be in the down or off position:

This will set the MIDI channel number to 1 and the display mode to 0 through 9.

See the previous figures for details on the different switch settings.

## Operating Instructions:

1. Set the RMC 2010 to the desired MIDI channel and display mode. (See previous figures.)
2. Turn the RMC 2010 **on** by plugging in the DC adaptor. The MIDI channel number will flash followed by a dash in each of the two LEDs located in the upper left corner of the unit.



3. To change the “bank” number press the (+) increment or (-) decrement switches. The left LED will display the “bank” number.

**Note:** The RMC 2010 has 13 “banks”: The first twelve have ten presets each and the last has eight presets for a total of 128 presets. The banks are numbered from 0 to 9, and A, b, C.

4. To change the preset number within a “bank,” press one of the numbered switches. The right LED will display the preset number.

**Note:** Each time a preset switch (switches labeled 0 through 9) is pressed, the corresponding MIDI program change command is sent to the receiving unit.

**THIS LIMITED WARRANTY VALID ONLY WHEN PURCHASED AND REGISTERED IN THE UNITED STATES OR CANADA. ALL EXPORTED PRODUCTS ARE SUBJECT TO WARRANTY AND SERVICES TO BE SPECIFIED AND PROVIDED BY THE AUTHORIZED DISTRIBUTOR FOR EACH COUNTRY.**

**Ces clauses de garantie ne sont valables qu'aux Etats-Unis et au Canada. Dans tous les autres pays, les clauses de garantie et de maintenance sont fixées par le distributeur national et mesurées par lui selon la législation en vigueur.**

**Diese Garantie ist nur in den USA und Kanada gültig. Alle Export-Produkte sind der Garantie und dem Service des Importeurs des jeweiligen Landes unterworfen.**

**Esta garantía es válida solamente cuando el producto es comprado en E.U. continentales o en Canada. Todos los productos que sean comprados en el extranjero, están sujetos a las garantías y servicio que cada distribuidor autorizado determine y ofrezca en los diferentes países.**

#### **ONE-YEAR LIMITED WARRANTY/REMEDY**

PEAVEY ELECTRONICS CORPORATION ("PEAVEY") warrants this product, EXCEPT for covers, footswitches, patchcords, tubes and meters, to be free from defects in material and workmanship for a period of one (1) year from date of purchase, PROVIDED, however that this limited warranty is extended only to the original retail purchaser and is subject to the conditions, exclusions and limitations hereinafter set forth:

#### **PEAVEY 90-DAY LIMITED WARRANTY ON TUBES AND METERS**

If this product contains tubes or meters, Peavey warrants the tubes or meters contained in the product to be free from defects in material and workmanship for a period of ninety (90) days from date of purchase; PROVIDED, however, that this limited warranty is extended only to the original retail purchaser and is also subject to the conditions, exclusions and limitations hereinafter set forth.

#### **CONDITIONS, EXCLUSIONS AND LIMITATIONS OF LIMITED WARRANTIES**

These limited warranties shall be void and of no effect if:

- The first purchase of the product is for the purpose of resale; or
- The original retail purchase is not made from an AUTHORIZED PEAVEY DEALER; or
- The product has been damaged by accident or unreasonable use, neglect, improper service or maintenance, or other causes not arising out of defects in material or workmanship; or
- The serial number affixed to the product is altered, defaced or removed.

In the event of a defect in material and/or workmanship covered by this limited warranty, Peavey will:

- In the case of tubes or meters, replace the defective component without charge;
  - In other covered cases (i.e., cases involving anything other than covers, footswitches, patchcords, tubes or meters), repair the defect in material or workmanship or replace the product, at Peavey's option;
- and provided, however, that, in any case, all costs of shipping, if necessary, are paid by you, the purchaser.

**THE WARRANTY REGISTRATION CARD SHOULD BE ACCURATELY COMPLETED AND MAILED TO AND RECEIVED BY PEAVEY WITHIN FOURTEEN (14) DAYS FROM THE DATE OF YOUR PURCHASE.**

In order to obtain service under these warranties, you must:

- Bring the defective item to any AUTHORIZED PEAVEY DEALER or AUTHORIZED PEAVEY SERVICE CENTER and present therewith the ORIGINAL PROOF OF PURCHASE supplied to you by the AUTHORIZED PEAVEY DEALER in connection with your purchase from him of this product.  
If the DEALER or SERVICE CENTER is unable to provide the necessary warranty service you will be directed to the nearest other PEAVEY AUTHORIZED DEALER or AUTHORIZED PEAVEY SERVICE CENTER which can provide such service.

**OR**

- Ship the defective item, prepaid, to:

PEAVEY ELECTRONICS CORPORATION  
International Service Center  
Highway 80 East  
MERIDIAN, MS 39301

including therewith a complete, detailed description of the problem, together with a legible copy of the original PROOF OF PURCHASE and a complete return address. Upon Peavey's receipt of these items:

If the defect is remedied under these limited warranties and the other terms and conditions expressed herein have been complied with, Peavey will provide the necessary warranty service to repair or replace the product and will return it, FREIGHT COLLECT, to you, the purchaser.

Peavey's liability to the purchaser for damages from any cause whatsoever and regardless of the form of action, including negligence, is limited to the actual damages up to the greater of \$500.00 or an amount equal to the purchase price of the product that caused the damage or that is the subject of or is directly related to the cause of action. Such purchase price will be that in effect for the specific product when the cause of action arose. This limitation of liability will not apply to claims for personal injury or damage to real property or tangible personal property allegedly caused by Peavey's negligence. Peavey does not assume liability for personal injury or property damage arising out of or caused by a non-Peavey alteration or attachment, nor does Peavey assume any responsibility for damage to interconnected non-Peavey equipment that may result from the normal functioning and maintenance of the Peavey equipment.

**UNDER NO CIRCUMSTANCES WILL PEAVEY BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, ANY INCIDENTAL DAMAGES OR ANY CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT, EVEN IF PEAVEY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.**

THESE LIMITED WARRANTIES ARE IN LIEU OF ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE; PROVIDED, HOWEVER, THAT IF THE OTHER TERMS AND CONDITIONS NECESSARY TO THE EXISTENCE OF THE EXPRESS, LIMITED WARRANTIES, AS HEREINABOVE STATED, HAVE BEEN COMPLIED WITH, IMPLIED WARRANTIES ARE NOT DISCLAIMED DURING THE APPLICABLE ONE-YEAR OR NINETY-DAY PERIOD FROM DATE OF PURCHASE OF THIS PRODUCT.

SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THESE LIMITED WARRANTIES GIVE YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

THESE LIMITED WARRANTIES ARE THE ONLY EXPRESS WARRANTIES ON THIS PRODUCT, AND NO OTHER STATEMENT, REPRESENTATION, WARRANTY OR AGREEMENT BY ANY PERSON SHALL BE VALID OR BINDING UPON PEAVEY.

In the event of any modification or disclaimer of express or implied warranties, or any limitation of remedies, contained herein conflicts with applicable law, then such modification, disclaimer or limitation, as the case may be, shall be deemed to be modified to the extent necessary to comply with such law.

Your remedies for breach of these warranties are limited to those remedies provided herein and Peavey Electronics Corporation gives this limited warranty only with respect to equipment purchased in the United States of America.

#### **INSTRUCTIONS — WARRANTY REGISTRATION CARD**

- Mail the completed WARRANTY REGISTRATION CARD to:

PEAVEY ELECTRONICS CORPORATION  
POST OFFICE BOX 2898  
MERIDIAN, MISSISSIPPI 39302-2898

- Keep the PROOF OF PURCHASE. In the event warranty service is required during the warranty period, you will need this document. **There will be no identification card issued by Peavey Electronics Corporation.**
- IMPORTANCE OF WARRANTY REGISTRATION CARDS AND NOTIFICATION OF CHANGES OF ADDRESS:**
  - Completion and mailing of WARRANTY REGISTRATION CARDS — Should notification become necessary for any condition that may require correction, the REGISTRATION CARD will help ensure that you are contacted and properly notified.
  - Notice of address changes — If you move from the address shown on the WARRANTY REGISTRATION CARD, you should notify Peavey of the change of address so as to facilitate your receipt of any bulletins or other forms of notification which may become necessary in connection with any condition that may require dissemination of information or correction.
- You may contact Peavey directly by telephoning (601) 483-5365.
- Please have the Peavey product name and serial number available when communicating with Peavey Customer Service.

**EXPOSURE TO EXTREMELY HIGH NOISE LEVELS MAY CAUSE A PERMANENT HEARING LOSS. INDIVIDUALS VARY CONSIDERABLY IN SUSCEPTIBILITY TO NOISE INDUCED HEARING LOSS, BUT NEARLY EVERYONE WILL LOSE SOME HEARING IF EXPOSED TO SUFFICIENTLY INTENSE NOISE FOR A SUFFICIENT TIME.**  
**THE U.S. GOVERNMENT'S OCCUPATIONAL SAFETY AND HEALTH ADMINISTRATION (OSHA) HAS SPECIFIED THE FOLLOWING PERMISSIBLE NOISE LEVEL EXPOSURES:**

DURATION PER DAY IN HOURS	SOUND LEVEL dBA, SLOW RESPONSE
8	91
6	93
4	95
3	97
2	100
1½	102
1	105
¾	110
½	115

ACCORDING TO OSHA, ANY EXPOSURE IN EXCESS OF THE ABOVE PERMISSIBLE LIMITS COULD RESULT IN SOME HEARING LOSS.

EAR PLUGS OR PROTECTORS IN THE EAR CANALS OR OVER THE EARS MUST BE WORN WHEN OPERATING THIS AMPLIFICATION SYSTEM IN ORDER TO PREVENT A PERMANENT HEARING LOSS IF EXPOSURE IS IN EXCESS OF THE LIMITS AS SET FORTH ABOVE. TO INSURE AGAINST POTENTIALLY DANGEROUS EXPOSURE TO HIGH SOUND PRESSURE LEVELS, IT IS RECOMMENDED THAT ALL PERSONS EXPOSED TO EQUIPMENT CAPABLE OF PRODUCING HIGH SOUND PRESSURE LEVELS, SUCH AS THIS AMPLIFICATION SYSTEM, BE PROTECTED BY HEARING PROTECTORS WHILE THIS UNIT IS IN OPERATION.

THIS MIXER/CONSOLE/STREET'S DEVICE/PAIRER HAS BEEN DESIGNED AND CONSTRUCTED TO PROVIDE ADEQUATE SIGNAL VOLTAGE FOR PLAYING MODERN MUSIC. PROPER USE OF THE GAIN/EQUALIZER CONTROLS AND/OR MAXIMUM USE OF INTERNAL/EXTERNAL SPEAKERS MAY ORIGINATE CLIPPING (SQUARE WAVES) AND POSSIBLY CAUSE SUBSEQUENT DAMAGE TO THE LOUDSPEAKER SYSTEMS. EXTENDED OPERATION OF THE GAIN/EQUALIZER CONTROLS IN THEIR MAXIMUM POSITIONS IS THEREFORE NOT RECOMMENDED. PLEASE REMEMBER THAT MAXIMUM POWER CAN BE OBTAINED WITH VERY LOW SETTINGS OF THE GAIN/EQUALIZER CONTROLS IF THE INPUT SIGNAL IS VERY STRONG.

IT IS COMMON PRACTICE AMONG USERS OF SOUND REINFORCEMENT EQUIPMENT TO IDENTIFY THE INDIVIDUAL CHANNELS WITH A STRIP OF TAPE PLACED ABOVE OR BELOW THE POWER VOLUME FADERS. MANY TYPES OF BRANDS OF TAPE HAVE VERY STRONG ADHESIVE WHICH CAN INHIBIT THE PAINT ON THE FACERETTE AND JUST AS EASILY REMOVE THE PAINT WHEN THE TAPE IS REMOVED. WE STRONGLY RECOMMEND THAT SCOTCH TAPE BE USED ON THE FACERETTE OR ANY OTHER TAPE THAT IS NOT SPECIALLY DESIGNED FOR ADHESION. VENTILATION HOLES OR LIGHT ADHESIVE WHEN USING SCOTCH TAPE IS RECOMMENDED IF TAPE IS USED ANYTIME LEFT ON PAINTED SURFACE FOR EXTENDED PERIODS WILL BE DIFFICULT TO REMOVE. NEVER USE CARBOR SCOTCH TAPE ON ANY APPLICATIONS.

1. Read all safety and operating instructions before using this product.
2. All safety and operating instructions should be retained for future reference.
3. Obey all cautions in the operating instructions and on the back of the unit.
4. All operating instructions should be followed.
5. This product should not be used near water, i.e., a bathtub, sink, swimming pool, wet basement, etc.
6. This product should be located so that its position does not interfere with its proper ventilation. It should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
7. This product should not be placed near a source of heat such as a stove, radiator or another heat producing appliance.
8. Connections to a power supply of the type marked on this unit adjacent to the power supply cord.
9. Never break off the ground pin on the power supply cord. For more information on grounding, write for our free booklet "Shock Hazards and Grounding."
10. Power supply cords should always be handled carefully. Never walk or place equipment on power supply cords. Periodically check cords for cuts or signs of stress, especially at the plug and the point where the cord exits the unit.
11. The power supply cord should be unplugged when the unit is to be unused for long periods of time.
12. If this product is to be mounted in an equipment rack, rear support should be provided.
13. Motor parts can be cleaned with a damp rag. The vinyl covering used on some units can be cleaned with a damp rag, or an ammonia based household cleanser if necessary.
14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation holes or any other openings.
15. This unit should be checked by a qualified service technician if:
  - A. The power supply cord or plug has been damaged.
  - B. Anything has fallen on or been spilled into the unit.
  - C. The unit does not operate correctly.
  - D. The unit has been dropped or the enclosure damaged.
16. The user should not attempt to service this equipment. All service work should be done by a qualified service technician.



Features and specifications subject to change without notice.

Peavey Electronics Corporation 711 A Street / Meridian, MS 39302-2898 / U.S.A. / (601) 483-5365 / Telex: 504115 / Fax: 484-4278